

-01

Driver Board only, no enclosure

The LE P*X-01 driver is based on the standard LE P*X driver without any enclosure.

PCB only.

Functional details and dimensions on the LE P*X datasheet applies the same to the LE P*X-01.

Toll Free

Tel: 1 (888) 626-4365
Fax: 1 (800) 263-5807

Local & International

Tel: +1 (905) 363-2400
Fax: +1 (905) 363-1191

Canada (Headquarters)

1799 Argentia Road
Mississauga, Ontario L5N 3A2

USA

3790 Commerce Court, Suite 500,
North Tonawanda, NY, 14120